

## Chemiflex® Composite Hose Type 834

### Applications

This type is designed for the transfer of hydrocarbons, including oils, petroleum products, diesel, lubricating oils, paraffin and 100% aromatics in heavy duty marine operations including ship and barge loading and unloading. A stainless steel outer wire is available for applications which include a corrosive environment.



### Technical description

Lining	: PTFE
Inner Wire	: Galvanized Steel
Outer Wire	: GGF834 Galvanized Steel GSF834 Stainless Steel 304 or 316
Cover	: PVC coated Nylon, Abrasion, UV and ozone resistant, Red
Temperature range	: -30°C to + 100°C (-22°F to + 212°F)
Electrical properties	: Electrically conductive
Standard	: EN13765:2018, Type 3
Complies with	: IMO IBC code
Approval	: ClassNK Certificate N0. TA21511E(AL)

### Physical properties

Maximum elongation	: 10% on test pressure
Vacuum range	: 0,9 bar

### End Fittings

Specially designed end fittings have been developed for use with Amniflex Composite hoses, including threaded ends, flanged ends and other connections. By means of a hydraulic operated press, a ferrule is externally swaged onto the hose to secure the hose shank and guarantee a leak proof connection between hose and fitting. All ferrules are welded to the end fitting before swaging for even safer operating conditions.

**Technical data: Type GGF834/GSF834**

Inside Diameter		Working Pressure		Min. Bend Radius		Approx. Weight		Max. length	
inches	mm	psi	Bar	inches	mm	lbs/ft	kg/m	ft.	m
1	25	200	14	4	100	0,75	1,10	65	20
1 ½	40	200	14	5¼	130	0,85	1,40	65	20
2	50	200	14	5½	140	1,35	2,00	65	20
2 ½	65	200	14	6½	165	1,75	2,60	65	20
3	80	200	14	9	230	2,50	3,70	65	20
4	100	200	14	15	380	4,40	6,50	65	20
5	125	200	14	17	435	5,80	8,60	65	20
6	150	200	14	18	460	7,00	10,50	79	24
8	200	200	14	27	690	12,00	18,00	65	20
10	250	150	10	36	920	15,00	23,00	50	15

\* 10"=Type 2  
Safety factor acc. EN 13765:2018

All information in this document is without any obligation, specifications subject to change without any notice.

### Amniflex B.V.

Abraham van Stolkweg 118  
3041 JA, Rotterdam  
T: +31(0)10 2982121  
E: amniflex@plastiflex.com  
www.amniflex.com

BTW nr. NL862140729B01  
Bank: KBC Bank NV  
KREDNL2XXXX  
IBAN NL23 KRED0633024376

K.v.K. Rotterdam nr. 81568053

Al onze aanbiedingen en leveranties geschieden volgens onze algemene leveringsvoorwaarden.

